


Model 123
126 up through 08.1985



Visual inspection

Hydraulic fluid pump

Fluid reservoir

Level controller

Pressure reservoir

Spring struts

Line connections

Check hoses and lines for chafing, dents, cracks, corrosion, and leaks (with engine running).

Note: To check for leaks that may only occur when the vehicle is loaded, check vehicle with the engine running and with vehicle rear loaded with approx. 150 kg (or 2 persons).